

Balancing Valve Installation Instructions



Applications

The Flow Guard can be used to balance Heating, Cooling, Radiant, Solar, Heat Pump or other water flow systems in Flow ranges using pipe sizes from $\frac{3}{4}$ " to 1 $\frac{1}{4}$ ".

Installations

Flow Guard works in any position – horizontal, vertical, up or down flow. The flow direction is indicated with an arrow on the solid brass body. The union connections give sufficient straight pipe run to get accurate flow readings. To facilitate reading of the flow rate, rotate the gray rate indicator to the best position.

Balancing to the Desired Flow Rate

The balancing valve can be adjusted with an Allen key (4mm or 5/32".) Adjust the rate with all systems operating. The balancing screw might need many revolutions. This valve design allows exact adjustment with the lowest noise emission.

Main Features

Accuracy ± 8%Main flow of water does not enter Flow IndicatorInstallation can be in any directionHigh temperature rating 212°F (100°C)Multi-turn adjustment for exact flow rateHigh pressure rating 150 psi (10 bar)Flow can be shut offAccurate reading even with glycol solutions

Technical Specifications

Maximum Temperature:	212°F (100°C) Flow Range:	#2907	3⁄4"	0.5-4 gpm
Maximum Pressure:	150 psi (10 bar)	#2908	3⁄4"	1-9 gpm
		#2911	1"	1-13 gpm
		#2912	1 ¼"	2-21 gpm

Material

Housing: solid brass Flow Meter: impact resistant and temperature stable fiberglass and plastic Flow Indicator Spring: stainless steel Seals: EPDM Elastomers

Specifications are subject to change without notice.




5 Park Lake Road, Sparta NJ 07871 PHONE: (973) 383 9888 FAX: (973) 383 9088 www.istec-corp.com



FlowGuard-Memory

Sizes 1" and 1 1/4"



The memory stop allows return to previous flow rate setting after Flowguard has been used as a stop valve. (Totally closed flow)

Technical Specifications:

Model #	Size	Indicator Range	Cv	Temp Range	Max. Pressure
2911	1"	1 -13 GPM	6.4	0°F-212°F	150 psi
2912	1 ¼"	2 -21 GPM	10.5	0°F-212°F	150 psi